



210-03/610-03


Place this manual with personal responsible for maintenance of this valve



INSTALLATION



OPERATION




MAINTENANCE



Distributed By: M&M Control Service, INC. Phone: 800-876-0036 Fax: 847-356-0747

Email: Sales@mmcontrol.com



		CVCL	1 (2) 3	4	DIST CODE	002	SI	HEFT	2 OF	3
	GLA-VAL GO.	NEWPORT	BEAC	H, CAUF	ORNIA	210-03/6	610-03	DRAWNG	804	-20	REV J
ľ	TYPE OF VALVE AND MAIN FEATURES	/AV F	1.01	AL TN	'nE	/FOUNDDED	WITH	DESIGN			prost 2000-00-00-00
	ALTITUDE VALVE — ONE V DIFFERENTIAL CONTROL TO	VAY F DEL		OPE	MIN	1		DRAW	MC		11-3-81
ł		EL-OF						CHK'D	K[2010 VANUE - D COO	12-4-81
	LOWERING RESERVOIR LEV	LL O	LIV	1110		INT ADOUGH	(OCL)	APYU	Çŀ		12-7-81

OPERATING DATA

ALTITUDE VALVE FEATURE:

ALTITUDE CONTROL (2) IS A SPRING LOADED, 3-WAY, DIAPHRAGM ACTUATED CONTROL THAT SENSES PRESSURE IN THE RESERVOIR. WHEN RESERVOIR PRESSURE (LIQUID LEVEL) IS LOWER THAN THE SET POINT OF CONTROL (2), PORTS "1" AND "D" ARE INTERCONNECTED. THIS RELIEVES MAIN VALVE COVER PRESSURE TO ATMOSPHERE AND THE MAIN VALVE OPENS TO FILL THE RESERVOIR. RESERVOIR SENSING PRESSURE INCREASES AS THE LIQUID LEVEL RISES IN THE RESERVOIR. WHEN RESERVOIR PRESSURE INCREASES TO THE SET POINT OF CONTROL (2), CONTROL (2) SHIFTS, INTERCONNECTING PORTS "S" AND "1". THIS PRESSURIZES THE MAIN VALVE ALTITUDE CONTROL (2) ADJUSTMENT: COVER AND THE MAIN VALVE CLOSES. TURN THE SPRING ADJUSTING NUT CLOCKWISE TO INCREASE THE LIQUID LEVEL SHUTOFF POINT; COUNTERCLOCKWISE TO DECREASE THE LIQUID LEVEL SHUTOFF POINT.

DELAYED OPENING FEATURE:

DATE

₽

MANUALLY

- DO NOT REVISE

REVISION RECORD

3

SHEET

SEE

FLOW CHECK CONTROL (6) IS CLOSED DURING THE RESERVOIR FILLING AS THE LIQUID LEVEL RISES IN THE RESERVOIR, CHECK VALVE (5) THIS DIRECTS STATIC RESERVOIR PRESSURE INTO THE SENSING CHAMBER OF ALTITUDE CONTROL (2). WHEN THE RESERVOIR IS FILLED AND THE MAIN VALVE CLOSES, THE LIQUID LEVEL HAS REACHED THE HIGH POINT AND CHECK VALVE (5) CLOSES. AS THE RESERVOIR LEVEL LOWERS, CHECK VALVE (5) REMAINS CLOSED, TRAPPING PRESSURE IN THE SENSING CHAMBER OF ALTITUDE CONTROL (2). WHEN THE LEVEL LOWERS TO THE DESIRED REOPEN POINT, FLOW CHECK CONTROL (6) OPENS AND RELEASES THE TRAPPED PRESSURE FROM THE RESERVOIR. FLOW CHECK CONTROL (6) TURN THE ADJUSTING SCREW CLOCKWISE TO INCREASE THE ADJUSTMENT: DELAY OF OPENING.

III. CLOSING SPEED CONTROL:

CV FLOW CONTROL (8) CONTROLS THE CLOSING SPEED OF THE MAIN VALVE. TURN THE ADJUSTING STEM CLOCKWISE TO MAKE THE MAIN VALVE CLOSE SLOWER.

IV. OPTIONAL FEATURE OPERATING DATA:

SUFFIX A (FLOW CLEAN STRAINER)

A SELF-CLEANING STRAINER IS INSTALLED IN THE MAIN VALVE INLET BODY BOSS WHICH PROTECTS THE PILOT SYSTEM FROM FOREIGN PARTICLES.

THIS DRAWING IS THE PROPERTY OF CLA-VAL CO. AND SAME AND COPIES MADE THEREOF, IF ANY, SHALL BE RETURNED TO IT UPON DEMAND. DELIVERY AND DISCLOSURE HEREOF ARE SOLELY UPON CONDITION THAT THE SAME SHALL NOT BE USED, COPIED OR REPRODUCED, NOR SHALL THE SUBJECT HEREOF BE DISCLOSED IN ANY MANNER TO ANYONE FOR ANY PURPOSE, EXCEPT AS HEREIN AUTHORIZED, WITHOUT PRIOR WRITTEN APPROVAL OF CLA-VAL CO. THIS DRAWING IS SUBMITTED CONFIDENTIALLY AND MAY NOT BE USED IN THE MANUFACTURE OF ANY MATERIAL OR PRODUCT OTHER THAN SUCH MATERIALS AND PRODUCTS FURNISHED TO CLA-VAL CO. WHETHER OR NOT THE COURMENT OR INFORMATION SHOWN HEREON IS PATENTED OR OTHERWISE PROTECTED, FULL TITLE AND COPYRIGHTS, IF ANY, IN AND TO THIS DRAWING AND/OR INFORMATION DELIVERED OR SUBMITTED ARE FULLY RESERVED CLA-VAL CO."

						CVCL	1 ②	3	4	DIST CO	DE 002	SH	IEET 3 OF	
		C	i_CL/	A-VAI	L CO	MEMPOR	RT BEACH,	CALIFOR	NIA	210-03	3/610-03	DRAWNG N	80420	rev J
		AL DIF	VALVE AND HAIN LTITUDE FFERENT OWERING	VALVE - IAL CON	- ONE TROL 1 OIR LE	WAY F O DEL VEL-O	FLOW LAY (PENII	TYF PEN NG F	PE (I NING POIN	EQUIPPEI OF VAL T ADJUS	D WITH VE ON STABLE)	DESIGN BRAW CHK'D APV'D	MG KD CH	11-3-81 12-4-81 12-7-81
						OPER	ATING	DA:	TA-	CONTINU	<u>ED</u>			
			CK2 CC	NE PRES), (B2)	& (B	3) AF	RE U LVES	SED MU	TO ISOL ST BE O	ATE THE PEN DUR	PILOT	T SYSTEM IORMAL	FROM
			WHEN (PENS AN	PRESSUI D (D1)	RE IS CLOSE	HIGHE S.	R T	HAN DIRI	ECTS THE	RESSURE, E HIGHER MAIN VA	OUTL	CK VALVE LET CLOSES.	Ξ
			PILOT S SUPPLY NOT SP	PRESSU	PRESSU JRE IS) NOTE	RE IS OBTAIN E: INDE	OBTA NED F EPENC	INEC ROM DENT	FR TH	OM AN II E MAIN N ERATING	VALVE INL	ET IF	OURCE. SUFFIX (ST BE ECL TIMES.	(F) IS
T P P			CDC CH DESIREI	H (PILO IECK VAI D. WHEN VALVE (LVE (H) N OUTLI	IS US	SED V	VHEN	I PIL	OT DRAII GHER THA	N TO ATA AN INLET	IOSPH PRES	IERE IS N SSURE.	ЮТ
N N			CV FLO	HE ADJU	ROL (S)	CONT	ROLS	THE			PEED OF THE MAIN		MAIN VAL VE OPEN	VE.
X MANUALLY			A Y-PA		STRAINE PILOT S	R IS I	FROM	A FC	REIC	N PARTI	OT SUPPL CLES. T			
CAD REVISION RECORD - DO NOT REVISE MANUA	SEE SHEET 1.	V.	() SYS () AIR HIG () CK () PEF () CV () CV () RES () IND	SH POINT 2 COCKS RIODIC CI FLOW CI FLOW CI SERVOIR	LVES O ED FRO S. S (B1), LEANING ONTROL ONTROL SENSIN IT OPER	PEN UM THE (B2) & (B2) & (B3) (C) (S) C G LINE RATING	IPSTR MAIN (B3 STRAII OPEN OPEN C PRO	EAM VA O OF NER AT AT	ANI LVE PEN (Y) LEAS LEAS	COVER A (OPTIONAL IS RECO ST 1/4 T ST 1/4 T CONNECTE	AND PILO AL FEATU MMENDED URN. URN (OP' ED.	RE). (OP1 TIONA	STEM AT A TIONAL FE L FEATUR CONNECT	ATURE).

THIS DRAWING IS THE PROPERTY OF CLA-VAL CO. AND SAME AND COPIES MADE THEREOF, IF ANY, SHALL BE RETURNED TO IT UPON DEMAND. DELIVERY AND DISCLOSURE HEREOF ARE SOLELY UPON CONDITION THAT THE SAME SHALL NOT BE USED, COPIED OR REPRODUCED, NOR SHALL THE SUBJECT HEREOF BE DISCLOSED IN ANY MAINER TO ANYONE FOR ANY PURPOSE, EXCEPT AS HEREIN AUTHORIZED, WITHOUT PRIOR WRITTEN APPROVAL OF CLA-VAL CO. THIS DRAWING IS SUBMITTED CONFORMATION FOR THAT BY USED IN THE MAINFACTURE OF ANY MEMBER OR PRODUCT OTHER THAN SUCH MATERIALS, AND PRODUCT SUBMITTED CONFORMATION OF CLA-VAL CO. WHETHER OR NOT THE COUPMENT OR NFORMATION SHOWN HEREON IS PATENTED OR OTHERWISE PROTECTED, FULL TITLE AND COPYRIGHTS, IF ANY, IN AND TO THIS DRAWING AND/OR INFORMATION DELIVERED OR SUBMITTED ARE FULLY RESERVED CLA-VAL CO."

INSTALLATION / OPERATION / MAINTENANCE




- MODEL - 100-01 Hytrol Valve

Description

The Cla-Val Model 100-01 Hytrol Valve is a main valve for Cla-Val Automatic Control Valves. It is a hydraulically operated, diaphragm-actuated, globe or angle pattern valve.

This valve consists of three major components; body, diaphragm assembly, and cover. The diaphragm assembly is the only moving part. The diaphragm assembly uses a diaphragm of nylon fabric bonded with synthetic rubber. A synthetic rubber disc, contained on three and one half sides by a disc retainer and disc guide, forms a seal with the valve seat when pressure is applied above the diaphragm. The diaphragm assembly forms a sealed chamber in the upper portion of the valve, separating operating pressure from line pressure.




Installation

- 1. Before valve is installed, pipe lines should be flushed of all chips, scale and foreign matter.
- 2. It is recommended that either gate or block valves be installed on both ends of the 100-01 Hytrol Valve to facilitate isolating the valve for preventive maintenance and repairs.
- 3. Place the valve in the line with flow through the valve in the direction indicated on the inlet nameplate. (See "Flow Direction" Section)
- 4. Allow sufficient room around valve to make adjustments and for disassembly.
- 5. Cla-Val 100-01 Hytrol Valves operate with maximum efficiency when mounted in horizontal piping with the cover UP, however,

other positions are acceptable. Due to size and weight of the cover and internal components of 8 inch and π arger valves, installation with the cover UP is advisable. This makes internal parts readily accessible for periodic inspection.


- 6. If a pilot control system is installed on the 100-01 Hytrol Valve, use care to prevent damage. If it is necessary to remove fittings or components, be sure they are kept clean and replaced exactly as they were.
- 7. After the valve is installed and the system is first pressurized, vent air from the cover chamber and pilot system tubing by loosening fittings at all high points.

Principles of Operation




Tight Closing Operation

When pressure from the valve inlet (or an equivalent independent operating pressure) is applied to the diaphragm chamber the valve closes drip-tight.



Full Open Operation

When pressure in diaphragm chamber is relieved to a zone of lower pressure (usually atmosphere) the line pressure (5 psi Min.) at the valve inlet opens the valve.



Modulating Action

Valve modulates when diaphragm pressure is held at an intermediate point between inlet and discharge pressure. With the use of a Cla-Val. "modulating control," which reacts to line pressure changes, the pressure above the diaphragm is varied, allowing the valve to throttle and compensate for the change.

Flow Direction

The flow through the 100-01 Hytrol Valve can be in one of two directions. When flow is "up-and-over the seat," it is in "normal" flow and the valve will fail in the open position. When flow is "overthe seat-and down," it is in "reverse" flow and the valve will fail in the closed position. There are no permanent flow arrow markings. The valve must be installed according to nameplate data.



Recommended Tools

- 1. Three pressure gauges with ranges suitable to the installation to be put at Hytrol inlet, outlet and cover connections.
- 2. Cla-Val Model X101 Valve Position Indicator. This provides visual indication of valve position without disassembly of valve.
- 3. Other items are: suitable hand tools such as screwdrivers, wrenches, etc. soft jawed (brass or aluminum) vise, 400 grit wet or dry sandpaper and water for cleaning.

Troubleshooting

The following troubleshooting information deals strictly with the Model 100-01 Hytrol Valve. This assumes that all other components of the pilot control system have been checked out and are in proper working condition. (See appropriate sections in Technical Manual for complete valve).

All trouble shooting is possible without removing the valve from the line or removing the cover. It is highly recommended to permanently install a Model X101 Valve Position Indicator and three gauges in unused Hytrol inlet, outlet and cover connections.

SYMPTOM	PROBABLE CAUSE	REMEDY		
	Closed cocks in control system, or in main line.	Open Cocks.		
Fails to Close	Lack of cover chamber pressure.	Check upstream pressure, pilot system, strainer, tubing, cocks, or needle valves for obstruction.		
	Diaphragm damaged. (See Diaphragm Check.)	Replace diaphragm.		
	Diaphragm assembly inoperative. Corrosion or excessive scale build up on valve stem. (See Freedom of Movement Check)	Clean and polish stem. Inspect and replace any damaged or badly eroded part.		
	Mechanical obstruction. Object lodged in valve. (See Freedom of Movement Check)	Remove obstruction.		
	Worn disc. (See Tight Sealing Check)	Replace disc.		
	Badly scored seat. (See Tight Sealing Check)	Replace seat.		
Fails to Open	Closed upstream and/or downstream isolation valves in main line.	Open valves.		
	Insufficient line pressure.	Check upstream pressure. (Minimum 5 psi flowing line pressure differential.		
	Diaphragm assembly inoperative. Corrosion or excessive buildup on valve stem. (See Freedom of Movement Check)	Clean and polish stem. Inspect and replace any damaged or badly eroded part.		
	Diaphragm damaged. (For valves in "reverse flow" only)	Replace diaphragm.		

After checking out probable causes and remedies, the following three checks can be used to diagnose the nature of the problem before maintenance is started. They must be done in the order shown.

Three Checks

The 100-01 Hytrol Valve has only one moving part (the diaphragm and disc assembly). So, there are only three major types of problems to be considered.

First: Valve is stuck - that is, the diaphragm assembly is not free to move through a full stroke either from open to close or vice versa.

Second: Valve is free to move and can't close because of a worn out diaphragm.

Third: Valve leaks even though it is free to move and the diaphragm isn't leaking.

CAUTION:

Care should be taken when doing the troubleshooting checks on the 100-01 Hytrol Valve. These checks do require the valve to open fully. This will either allow a high flow rate through the valve, or the downstream pressure will quickly increase to the inlet pressure. In some cases, this can be very harmful. Where this is the case, and there are no block valves in the system to protect the downstream piping, it should be realized that the valve cannot be serviced under pressure. Steps should be taken to remedy this situation before proceeding any further.

Diaphragm Check (#1)

- 1. Shut off pressure to the Hytrol Valve by slowly closing upstream and downstream isolation valves. **SEE CAUTION**.
- 2. Disconnect or close all pilot control lines to the valve cover and leave only one fitting in highest point of cover open to atmosphere.
- 3.With the cover vented to atmosphere, slowly open upstream isolation valve to allow some pressure into the Hytrol Valve body. Observe the open cover tapping for signs of continuous flow. It is not necessary to fully open isolating valve. Volume in cover chamber capacity chart will be displaced as valve moves to open position. Allow sufficient time for diaphragm assembly to shift positions. If there is no continuous flow, you can be quite certain the diaphragm is sound and the diaphragm assembly is tight. If the fluid appears to flow continuously this is a good reason to believe the diaphragm is either damaged or it is loose on the stem. In either case, this is sufficient cause to remove the valve cover and investigate the leakage. (See "Maintenance" Section for procedure.)

COVER CHAMBER CAPACITY (Liquid Volume displaced when valve opens)						
Valve size (inches)	Displa	cement				
	Gallons	Liters				
1 1/4	.020	.07				
1 1/2	.020	.07				
2	.032	.12				
2 1/2	.043	.16				
3	.080	.30				
4	.169	.64				
6	.531	2.0				
8	1.26	4.8				
10	2.51	9.5				
12	4.00	15.1				
14	6.50	24.6				
16	9.57	36.2				
24	29.00	109.8				

Freedom of Movement Check (#2)

- **4.** Determining the Hytrol Valve's freedom of movement can be done by one of two methods.
- **5.** For most valves it can be done after completing Diaphragm Check (Steps 1, 2, and 3). **SEE CAUTION**. At the end of step 3 the valve should be fully open.
- **6.** If the valve has a Cla-Val X101 Position Indicator, observe the indicator to see that the valve opens wide. Mark the point of maximum opening.
- 7. Re-connect enough of the control system to permit the application of inlet pressure to the cover. Open pilot system cock so pressure flows from the inlet into the cover.
- 8. While pressure is building up in the cover, the valve should close smoothly. There is a hesitation in every Hytrol Valve closure, which can be mistaken for a mechanical bind. The stem will appear to stop moving very briefly before going to the closed position. This slight pause is caused by the diaphragm flexing at a particular point in the valve's travel and is not caused by a mechanical bind.
- **9.** When closed, a mark should be made on the X101 Valve position indicator corresponding to the "closed" position. The distance between the two marks should be approximately the stem travel shown in chart.

STEM TRAVEL (Fully Open to Fully Closed)							
Valv	e Size (inches)	,	(inches)				
Inch	nes MM	Inches	MM				
1 1	/4 32	0.4	10				
1 1	/2 40	0.4	10				
2	50	0.6	15				
2 1	/2 65	0.7	18				
3	80	0.8	20				
4	100	1.1	28				
6	150	1.7	43				
8	200	2.3	58				
10	250	2.8	71				
12	300	3.4	86				
14	350	4.0	100				
16	400	4.5	114				
24	610	6.5	165				

- 10. If the stroke is different than that shown in stem travel chart this is a good reason to believe something is mechanically restricting the stroke of the valve at one end of its travel. If the flow does not stop through the valve when in the indicated "closed" position, the obstruction probably is between the disc and the seat. If the flow does stop, then the obstruction is more likely in the cover. In either case, the cover must be removed, and the obstruction located and removed. The stem should also be checked for scale build-up. (See "Maintenance, section for procedure.)
- 11. For valves 6" and smaller, the Hytrol Valve's freedom of movement check can also be done after all pressure is removed from the valve. SEE CAUTION. After closing inlet and outlet isolation valves and bleeding pressure from the valve, check that the cover chamber and the body are temporarily vented to atmosphere. Insert fabricated tool into threaded hole in top of valve stem, and lift the diaphragm assembly manually. Note any roughness. The diaphragm assembly should move smoothly throughout entire valve stroke. The tool is fabricated from rod that is threaded on one end to fit valve stem and has a "T" bar handle of some kind on the other end for easy gripping. (See chart in Step 4 of "Disassembly" Section.)
- 12. Place marks on this diaphragm assembly lifting tool when the valve is closed and when manually positioned open. The distance between the two marks should be approximately the stem travel shown in stem travel chart. If the stroke is different than that shown, there is a good reason to believe something is mechanically restricting the stroke of the valve. The cover must be removed, and the obstruction located and removed. The stem should also be checked for scale build-up. (See "Maintenance" Section for procedure.)

Tight Sealing Check (#3)

13. Test for seat leakage after completing checks #1 & #2 (Steps 1 to 12). SEE CAUTION. Close the isolation valve downstream of the Hytrol Valve. Apply inlet pressure to the cover of the valve, wait until it closes. Install a pressure gauge between the two closed valves using one of the two ports in the outlet side of the Hytrol. Watch the pressure gauge. If the pressure begins to climb, then either the downstream isolation valve is permitting pressure to creep back, or the Hytrol is allowing pressure to go through it. Usually the pressure at the Hytrol inlet will be higher than on the isolation valve discharge, so if the pressure goes up to the inlet pressure, you can be sure the Hytrol is leaking. Install another gauge downstream of isolating valve. If the pressure between the valves only goes up to the pressure on the isolation valve discharge, the Hytrol Valve is holding tight, and it was just the isolation valve leaking.

Maintenance

Preventative Maintenance


The Cla-Val Co. Model 100-01 Hytrol Valve requires no lubrication or packing and a minimum of maintenance. However, a periodic inspection schedule should be established to determine how the operating conditions of the system are affecting the valve. The effect of these actions must be determined by inspection.

Disassembly

Inspection or maintenance can be accomplished without removing the valve from the line. Repair kits with new diaphragm and disc are recommended to be on hand before work begins.

WARNING: Maintenance personnel can be injured and equipment damaged if disassembly is attempted with pressure in the valve. **SEE CAUTION.**

- 1. Close upstream and downstream isolation valves and independent operating pressure when used to shut off all pressure to the valve.
- 2. Loosen tube fittings in the pilot system to remove pressure from valve body and cover chamber. After pressure has been released from the valve, use care to remove the controls and tubing. Note and sketch position of tubing and controls for re-assembly. The schematic in front of the Technical Manual can be used as a guide when reassembling pilot system.
- 3. Remove cover nuts and remove cover. If the valve has been in service for any length of time, chances are the cover will have to be loosened by driving upward along the edge of the cover with a dull cold chisel.



On 6" and smaller valves block and tackle or a power hoist can be used to lift valve cover by inserting proper size eye bolt in place of the center cover plug. on 8" and larger valves there are 4 holes (5/8" — 11 size) where jacking screws and/or eye bolts may be inserted for lifting purposes. **Pull cover straight up** to keep from damaging the integral seat bearing and stem.

COVER CENTER PLUG SIZE						
Valve Size Thread Size (NPT)						
1 1/4"—1 1/2"	1/4"					
2"—3"	1/2"					
4"—6"	3/4"					
8"—10"	1"					
12"	1 1/4"					
14"	1 1/2"					
16"	2"					
24"	4 1/4"					

4. Remove the diaphragm and disc assembly from the valve body. With smaller valves this can be accomplished by hand by pulling straight up on the stem so as not to damage the seat bearing. On large valves, an eye bolt of proper size can be installed in the stem and the diaphragm assembly can be then lifted with a block and tackle or power hoist. Take care not to damage the stem or bearings. The valve won't work if these are damaged.

VALVE STEM	THREAD SIZE	ı
Valve Size	Thread Size (UNF Internal)	ı
1 1/4"—2 1/2"	10—32	ı
3"—4"	1/4—28	
6"—14"	3/8—24	
16"	1/2—20	ı
24"	3-12	


5. The next item to remove is the stem nut. Examine the stem threads above the nut for signs of mineral deposits or corrosion. If the threads are not clean, use a wire brush to remove as much of the residue as possible. Attach a good fitting wrench to the nut and give it a sharp "rap" rather than a steady pull. Usually several blows are sufficient to loosen the nut for further removal. On the smaller valves, the entire diaphragm assembly can be held by the stem in a vise equipped with soft brass jaws before removing the stem nut.

The use of a pipe wrench or a vise without soft brass jaws scars the fine finish on the stem. No amount of careful dressing can restore the stem to its original condition. Damage to the finish of the stem can cause the stem to bind in the bearings and the valve will not open or close.

- **6.** After the stem nut has been removed, the diaphragm assembly breaks down into its component parts. Removal of the disc from the disc retainer can be a problem if the valve has been in service for a long time. Using two screwdrivers inserted along the outside edge of the disc usually will accomplish its removal. Care should be taken to preserve the spacer washers in water, particularly if no new ones are available for re-assembly.
- 7. The only part left in the valve body is the seat which ordinarily does not require removal. Careful cleaning and polishing of inside and outside surfaces with 400 wet/dry sandpaper will usually restore the seat's sharp edge. If, however, it is badly worn and replacement is necessary, it can be easily removed.

Seats in valve sizes 1 1/4" through 6" are threaded into the valve body. They can be removed with accessory X109 Seat Removing Tool available from the factory. On 8" and larger valves, the seat is held in place by flat head machine screws. Use a tight-fitting, long shank screwdriver to prevent damage to seat screws. If upon removal of the screws the seat cannot be lifted out, it will be necessary to use a piece of angle or channel iron with a hole drilled in the center. Place it across the body so a long stud can be inserted through the center hole in the seat and the hole in the angle iron. By tightening the nut a uniform upward force is exerted on the seat for removal.

NOTE: Do not lift up on the end of the angle iron as this may force the integral bearing out of alignment, causing the stem to bind.



Lime Deposits

One of the easiest ways to remove lime deposits from the valve stem or other metal parts is to dip them in a 5-percent muriatic acid solution just long enough for the deposit to dissolve. This will remove most of the common types of deposits. **CAUTION: USE EXTREME CARE WHEN HANDLING ACID.** Rinse parts in water before handling. If the deposit is not removed by acid, then a fine grit (400) wet or dry sandpaper can be used with water.

Inspection of Parts

After the valve has been disassembled, each part should be examined carefully for signs of wear, corrosion, or any other abnormal condition. Usually, it is a good idea to replace the rubber parts (diaphragm and disc) unless they are free of signs of wear. These are available in a repair kit. Any other parts which appear doubtful should be replaced. WHEN ORDERING PARTS, BE SURE TO GIVE COMPLETE NAMEPLATE DATA, ITEM NUMBER AND DESCRIPTION.

NOTE: If a new disc isn't available, the existing disc can be turned over, exposing the unused surface for contact with the seat. The disc should be replaced as soon as practical.

Reassembly

- 1. Reassembly is the reverse of the disassembly procedure. If a new disc has been installed, it may require a different number of spacer washers to obtain the right amount of "grip" on the disc. When the diaphragm assembly has been tightened to a point where the diaphragm cannot be twisted, the disc should be compressed very slightly by the disc guide. Excessive compression should be avoided. Use just enough spacer washers to hold the disc firmly without noticeable compression.
- 2. MAKE SURE THE STEM NUT IS VERY TIGHT. Attach a good fitting wrench to the nut and give it a sharp "rap" rather than a steady pull. Usually several blows are sufficient to tighten the stem nut for final tightening. Failure to do so could allow the diaphragm to pull loose and tear when subjected to pressure.
- 3. Carefully install the diaphragm assembly by lowering the stem through the seat bearing. Take care not to damage the stem or bearing. Line up the diaphragm holes with the stud or bolt holes on the body. on larger valves with studs, it may be necessary to hold the diaphragm assembly up part way while putting the diaphragm over the studs.
- **4.** Put spring in place and replace cover. Make sure diaphragm is lying smooth under the cover.
- 5. Tighten cover nuts firmly using a cross-over pattern until all nuts are tight.
- 6. Test Hytrol Valve before re-installing pilot valve system.

Test Procedure After Valve Assembly


There are a few simple tests which can be made in the field to make sure the Hytrol Valve has been assembled properly. Do these before installing pilot system and returning valve to service. These are similar to the three troubleshooting tests.


1. Check the diaphragm assembly for freedom of movement after all pressure is removed from the valve. **SEE CAUTION**. Insert fabricated tool into threaded hole in top of valve stem, and lift the diaphragm assembly manually. Note any roughness, sticking or grabbing. The diaphragm assembly should move smoothly throughout entire valve stroke. The tool is fabricated from rod that is threaded on one end to fit valve stem (See chart in Step 4 of "Disassembly" section.) and has a "T" Bar handle of some kind on the other end for easy gripping.

Place marks on this diaphragm assembly lifting tool when the valve is closed and when manually positioned open. The distance between the two marks should be approximately the stem travel shown in stem travel chart. (See "Freedom of Movement Check" section.) If the stroke is different than that shown, there is a good reason to believe something is mechanically restricting the stroke of the valve. The cover must be removed, the obstruction located and removed. (See "Maintenance" Section for procedure.)


Due to the weight of the diaphragm assembly this procedure is not possible on valves 8" and larger. on these valves, the same determination can be made by carefully introducing a low pressure-less than five psi) into the valve body with the cover vented. **SEE CAUTION**. Looking in cover center hole see the diaphragm assembly lift easily without hesitation, and then settle back easily when the pressure is removed.


- 2. To check the valve for drip-tight closure, a line should be connected from the inlet to the cover, and pressure applied at the inlet of the valve. If properly assembled, the valve should hold tight with as low as ten PSI at the inlet. See "Tight Sealing Check" section.)
- 3. With the line connected from the inlet to the cover, apply full working pressure to the inlet. Check all around the cover for any leaks. Re-tighten cover nuts if necessary to stop leaks past the diaphragm.
- **4.** Remove pressure, then re-install the pilot system and tubing exactly as it was prior to removal. **Bleed air from all high points.**
- **5.** Follow steps under "Start-Up and Adjustment" Section in Technical Manual for returning complete valve back to service.







	PARTS LIST
Item	Description
1.	Pipe Plug
2.	Drive Screws (for nameplate)
3.	Hex Nut (8" and larger)
4.	Stud (8" and larger)
5.	Cover Bearing
6.	Cover
7.	Stem Nut
8.	Diaphragm Washer
9.	Diaphragm
10.	Spacer Washers
11.	Disc Guide
12.	Disc Retainer
13.	Disc
14.	Stem
15.	Seat
16.	Body
17.	Spring
22.	Flat Head Screws (8" and larger)
23.	Seat O-Ring
24.	Hex head Bolt (1 1/4" thru 4")
25.	Nameplate
26.	Upper Spring Washer (Epoxy coated valves only)
27.	Lower Spring Washer (Epoxy coated valves only)
28.	Cover Bearing Housing (16" only)
29.	Cover O-Ring (16" only)
30.	Hex Bolt (16" only)
31.	Pipe Cap (16" only)










Distributed By: M&M Control Service, INC.



-MODEL- 100-20

600 Series **Hytrol Valve**



- Reduced Cavitation Design
- Drip-tight, Positive Seating Action
- Service Without Removal From Line
- Globe or Angle Pattern
- Every Valve Factory-Tested


The Cla-Val Model 100-20 Hytrol Valve is a hydraulically operated, diaphragm actuated, globe or angle pattern valve. It consists of three major components: body, diaphragm assembly and cover. The diaphragm assembly is the only moving part.

The diaphragm assembly is guided top and bottom by a precision machined stem which utilizes a non-wicking diaphragm of nylon fabric bonded with synthetic rubber. A resilient synthetic rubber disc, retained on three and one-half sides by a disc retainer, forms a drip-tight seal with the renewable seat when pressure is applied above the diaphragm.

The reduced cavitation characteristics of the 100-20 Hytrol Valve is the basis for the Cla-Val 600 Series. The rugged simplicity of design and packless construction assure a long life of dependable, trouble-free operation. It's smooth flow passages and fully guided disc and diaphragm assembly assure optimum control when used in piping systems requiring remote control, pressure regulation, solenoid operation, rate of flow control or check valve operation.


Available in various materials and in a wide range of sizes. It's applications are unlimited.

Principle of Operation




Full Open Operation

When pressure in the cover chamber is relieved to a zone of lower pressure, the line pressure at the valve inlet opens the valve, allowing full flow.



Tight Closing Operation

When pressure from the valve inlet is applied to the cover chamber, the valve closes drip-tight.



Modulating Action

The valve holds any intermediate position when operating pressure is equal above and below the diaphragm. Using a Cla-Val "Modulating" Control will allow the valve to automatically compensate for line pressure changes.

Specifications Model 100 -20

Available Sizes

Pattern	Flanged
Globe	3",4",6",8",10",12",14",16",18",20",24",30"
Angle	4",6",8"

Operating Temp. Range

Fluids	
-40° to 180° F	

Pressure Ratings (Recommended Maximum Pressure - psi)

Valve Body	& Cover	Pressure Class			
	Flanged				
Grade	Material	ANSI Standards*	150 lb.	300 lb.	
ASTM A536	Ductile Iron	B16.42	250	400	
ASTM A216-WCB	Cast Steel	B16.5	285	400	
ASTM B62	Bronze	B16.24	225	400	
ASTM A743	Stainless Steel	B16.5	285	400	
356-T6	Aluminum	B16.1	275	_	

Note: *ANSI standards are for flange dimensions only. Flanged valves are available faced but not drilled.

Materials

Component	Material Options					
Body & Cover	Ductile Iron	Cast Steel	Bronze	Stainless Steel	Aluminum	
Available Sizes	3" - 30"	3" - 30"	3" - 16"	3" - 16"	3" - 16"	
Disc Retainer & Diaphragm Washer	Cast Iron	Cast Steel	Bronze	Stainless Steel	Aluminum	
Trim: Disc Guide, Seat & Cover Bearing	Bronze is s Stainless S	tandard. teel is optional.	Stainless Stee	el is standard.		
Disc	Buna-N° Rubber					
Diaphragm	Nylon Reinforced Buna-N® Rubber					
Stem, Nut & Spring	Stainless Steel					

Options

Epoxy Coating - suffix KC

An FDA approved fusion bonded epoxy coating for use with cast iron, ductile iron or steel valves. This coating is resistant to various water conditions, certain acids, chemicals, solvents and alkalies. Epoxy coatings are applied in accordance with AWWA coating specifications C550-90. Do not use with temperatures above 175° F.

Dura-Kleen® Stem - suffix KD

This stem is designed for applications where water supplies containing dissolved minerals create deposits that build-up on a standard stem and hamper valve operation. A patented self-cleaning design on the stem allows all valve sizes to operate freely in the harshest conditions.

Delrin® Sleeved Stem - suffix KG

The Delrin® sleeved stem is designed for applications where water supplies contain

dissolved minerals which can form deposits that build up on the valve stem and hamper valve operation. Scale build-up will not adhere to the Delrin® sleeve stem. Delrin® sleeved stems are not recommended for valves in continuous operation where differential pressures are in excess of 80 psi (2" and larger Hytrol valves).

Water Treatment Clearance - suffix KW

This additional clearance is beneficial in applications where water treatment compounds can interfere with the closing of the valve. The smaller outside diameter disc guide provides more clearance between the disc guide and the valve seat. This option is best suited for valves used in on-off (non-modulating) service.

Viton® Rubber Parts - suffix KB

Optional diaphragm, disc and o-ring fabricated with Viton® synthetic rubber. Viton® is well suited for use with mineral



3" Globe, Flanged



6" Globe, Flanged



6" Angle, Flanged

acids, salt solutions, chlorinated hydrocarbons, and petroleum oils; and is primarily used in high temperature applications up to 250° F. Do not use with epoxy coatings above 175° F.

Heavy Spring - suffix KH

The heavy spring option is used in applications where there is low differential pressure across the valve, and the additional spring force is needed to help the valve close. This option is best suited for valves used in on-off (non-modulating) service.

For assistance in selecting appropriate valve options or valves manufactured with special design requirements, please contact our Regional Sales Office or Factory.

Functional Data Model 100 - 20

Valve	Size	Inches	3	4	6	8	10	12	14	16	18	20	24	30
Valve	mm.		80	100	150	200	250	300	350	400	460	510	610	760
	Globe	Gal./Min. (gpm)	62	136	229	480	930	1458	1725	2110	2940	3400*	3500*	7900*
_c_v	Pattern	Litres/Sec. (I/s)	15	32.5	55	115	223	350	414	506	705	816	840	1895
Factor	Angle	Gal./Min. (gpm)	_	135	233	545	_	_	_	_	_	_		
	Pattern	Litres/Sec. (I/s)	_	32	56	132	_	_	_	_	_	_	_	_
Equivalent	Globe	Feet (ft)	293	251	777	748	621	654	750	977	983	1125	3005	2130
Length of	Pattern	Meters (m)	89.3	76.4	237.1	228.1	189.5	199.4	228.7	298.1	299.9	343.2	916.6	649.6
Pipe	Angle	Feet (ft)	_	254	751	580			_	_		_		_
	Pattern	Meters (m)	_	77.6	229	176.9	_		_	_	-	_		_
К	Globe I	Pattern	20.6	12.7	23.1	15.7	10.4	8.5	8.9	10.2	8.4	8.8	19.1	10.5
Factor	Angle I	Pattern	_	12.9	22.3	12.2	_	_	_	_	_	_	_	_
		Fl. Oz	_	_	_	_	_	_	_	_	_	_	_	_
Liquid Dia		U.S. Gal.	.032	.08	.17	.53	1.26	2.51	4	4	9.6	9.6	9.6	29.0
Chambe	r When	ml	_		_	_	_		_	_		_	1	
Valve C	Opens	Litres	.12	.30	.64	2.0	4.8	9.5	15.1	15.1	36.2	36.2	36.2	110

^{*}Estimated

C_V Factor

Formulas for computing C_V Factor, Flow (Q) and Pressure Drop ($\triangle P$):

$$C_V = \frac{Q}{\sqrt{\triangle P}}$$
 $Q = C_V \sqrt{\triangle P}$ $\triangle P = \left(\frac{Q}{C_V}\right)^2$

K Factor (Resistance Coefficient)
The Value of K is calculated from the formula: $K = \frac{894 d^4}{C_V^2}$ (U.S. system units)

Equivalent Length of Pipe

Equivalent length of pipe (L) are determined from the formula: L = Kd 12f (U.S. system units)

Fluid Velocity

Fluid velocity
Fluid velocity can be calculated from the following formula: $V = \frac{.4085 \text{ Q}}{d^2}$ (U.S. system units) (U.S. system units)

Where:

C_V = U.S. (gpm) @ 1 psi differential at 60° F water

= (l/s) @ 1 bar (14.5 PSIG) differential at 15° C water

d = inside pipe diameter of Schedule 40 Steel Pipe (inches)

f = friction factor for clean, new Schedule 40 pipe (dimensionless) (from Cameron Hydraulic Data, 18th Edition)

K = Resistance Coefficient (calculated)


L = Equivalent Length of Pipe (feet)


Q = Flow Rate in U.S. (gpm) or (l/s)


V = Fluid Velocity (feet per second) or (meters per second)

 $\Delta \mathbf{P}$ = Pressure Drop in (psi) or (bar)

Model 100-20 Flow Chart (Based on normal flow through a wide open valve)







Model 100 -20

100-20 (Angle)

VALVE SIZE (Inches)	3	4	6	8	10	12	14	16	18	20	24	30
A 150 ANSI	10.25	13.88	17.75	21.38	26.00	30.00	34.25	35.00	42.12	48.00	48.00	63.25
AA 300 ANSI	11.00	14.50	18.62	22.38	27.38	31.50	_	36.62	43.63	49.62	49.75	_
B DIA.	6.62	9.12	11.50	15.75	20.00	23.62	28.00	28.00	35.44	35.44	35.44	53.19
C MAX.	7.00	8.62	11.62	15.00	17.88	21.00	20.88	25.75	25.00	31.00	31.00	43.94
D 150 ANSI	_	6.94	8.88	10.69	_	_	_	_	_	_	_	_
DD 300 ANSI	_	7.25	9.38	11.19	_	_	_	_	_	_	_	_
E 150 ANSI	_	5.50	6.75	7.25	_	_	_	_	_	_	_	_
EE 300 ANSI	_	5.81	7.25	7.75	_	_	_	_	_	_	_	_
F 150 ANSI	3.75	4.50	5.50	6.75	8.00	9.50	11.00	11.75	15.88	14.56	17.00	19.88
FF 300 ANSI	4.12	5.00	6.25	7.50	8.75	10.25	_	12.75	15.88	16.06	19.00	_
G NPT Body Tapping	3/8	1/2	3/4	3/4	1	1	1	1	1	1	1	1
H NPT Cover Center Plug	1/2	1/2	3/4	3/4	1	1	11/4	11/4	2	2	2	2
J NPT Cover Tapping	3/8	1/2	3/4	3/4	1	1	1	1	1	1	1	1
Valve Stem Internal												
Thread UNF	10-32	1/4-28	1/4-28	3/8 -24	%-24	%-24	%-24	%-24	1/2-20	1/2-20	1/2-20	3/4-16
Stem Travel	0.6	0.8	1.1	1.7	2.3	2.8	3.4	3.4	4.5	4.5	4.5	6.5
Approx Ship Wt. Lbs.	45	85	195	330	625	900	1250	1380	1500	2551	2750	6500

VALVE SIZE (mm)	80	100	150	200	250	300	350	400	450	500	600	750
A 150 ANSI	260	353	451	543	660	762	870	889	1070	1219	1219	1607
AA 300 ANSI	279	368	473	568	695	800		930	1108	1260	1263	
B DIA.	168	232	292	400	508	600	711	711	900	900	900	1351
C MAX.	178	219	295	381	454	533	530	654	635	787	787	1116
D 150 ANSI	_	176	226	272							_	_
DD 300 ANSI	_	184	238	284	_	_	_	_	_	_	_	_
E 150 ANSI		140	171	184								
EE 300 ANSI		148	184	197								
F 150 ANSI	95	114	140	171	203	241	279	298	403	370	432	505
FF 300 ANSI	105	127	159	191	222	260	_	324	403	408	483	_
G NPT Body Tapping	3/8	1/2	3/4	3/4	1	1	1	1	1	1	1	1
H NPT Cover Center Plug	1/2	1/2	3/4	3/4	1	1	11/4	11/4	2	2	2	2
J NPT Cover Tapping	3/8	1/2	3/4	3/4	1	1	1	1	1	1	1	1
Valve Stem Internal												
Thread UNF	10-32	1/4-28	1/4-28	%-24	3/s -2 4	%-24	%-24	3/s -2 4	½ -20	½-20	1/2-20	1/2-20
Stem Travel	15	20	28	43	58	71	86	86	86	114	114	165
Approx. Ship Wt. Kgs.	20	39	89	150	284	409	568	627	681	1157	1249	2951

Service and Installation

Cla-Val Control Valves operate with maximum efficiency when mounted in horizontal piping with the main valve cover UP, however, other positions are acceptable. Due to component size and weight of 10 inch and larger valves, installation with cover UP is advisable. We recommend isolation valves be installed on inlet and outlet for maintenance. Adequate space above and around the valve for service personnel should be considered essential. A regular maintenance program should be established based on the specific application data. However, we recommend a thorough inspection be done at least once a year. Consult factory for specific recommendations.




Distributed By:

M&M Control Service, INC.

Fax: 847-356-0747

Email: Sales@mmcontrol.com

100-20 (R-11/01)





Technical Bulletin



CDS6 Improvements

Recently, our Engineering Department redesigned a few internal parts of the CDS6 Pilot Control used on 210 Series Altitude Valves. These new parts improve its sensitivity at high differential pressures and allow it to work with inlet supply pressures up to 300 psi (previous maximum recommended pressure was 150 psi). The new control is identified as CDS6A and new part numbers are assigned to distinguish it from the original CDS6. Adjustment ranges remain the same.


New parts inside the CDS6A are a) stem seals, b) disc and poppet assembly, c) lower stem, d) lower cover, e) poppet guide, and f) poppet spring. The CDS6A uses new low-friction seals on the lower stem and the disc and poppet assembly. Also, the new stem and poppet have a special low-friction nickel-Teflon coating and are dimensionally interchangeable with CDS6 parts. The new lower cover and poppet guide have larger internal dimensions for the new seals and are not interchangeable with CDS6 parts. Also, the poppet spring has a heavier load and is not interchangeable. All other parts remain the same.

All bills of material for top assemblies using the CDS6 have been changed to the new control. It will take some time for us to change assembly drawings and deplete existing parts before we begin using the CDS6A. We plan to finalize the change during first quarter of 2003.

A new CDS6A repair kit is p/n 20349401C and will not work with existing CDS6 controls. The repair kit will include instructions and tools to install new stem seals. When servicing existing CDS6 controls the current repair kit p/n 20119301A should be used.

A modification kit consisting of all new parts and instructions is p/n 20354801G. Field modification is recommended only for installations where it is determined to be necessary.

Range (ft)	size	p/n	size	p/n
5 - 40	2 1/2" & larger	20354701K	2" & smaller	20354706E
30 - 80	2 1/2" & larger	20354702J	2" & smaller	20354707D
70 - 120	2 1/2" & larger	20354703H	2" & smaller	20354708C
110 - 160	2 1/2" & larger	20354704G	2" & smaller	20354709B
150 - 200	2 1/2" & larger		2" & smaller	20354710J



NEW CDS6A PARTS ARE ABOVE NUMBERED ITEMS.

- A) All other parts are the same as current CDS6 parts.
- **B)** Two new low-friction U-Seals, Item 1, will not fit into O-ring grooves of CDS6 lower cover and poppet guide. The machined groove dimensions are different between the O-ring version and the new U-seal version parts. New Lower Cover, Item 5, and Poppet Guide, Item 7, have proper dimensions for U-Seal.
- **C)** Lower Stem, Item 2, and Poppet, Item 3, are dimensionally interchangeable with CDS6 parts that are now obsolete. These new parts have a special low-friction coating which may enhance CDS6 performance.
- **D)** Poppet Spring, Item 6, has a heavier load rating and is not interchangeable with CDS6 poppet spring. Sensitivity will be greater than a 12" differential, if used in CDS6 controls.

INSTALLATION / OPERATION / MAINTENANCE



- MODEL - CDS6

ALTITUDE CONTROL

INTRODUCTION

The Cla-Val Model CDS6 Altitude Control is a spring loaded, 3-way, diaphragm-actuated control that provides high-level shut-off for Cla-Val Altitude Control Valves. It remotely senses pressure in the reservoir or tank. There are five altitude ranges available, 5 to 40 feet, 30 to 80 feet, 70 to 120 feet, 110 to 160 feet and 150 to 200 feet. The spring adjusting nut can be set to stop flow into the reservoir within these ranges.

INSTALLATION

The CDS6 Altitude Pilot Control is normally supplied mounted on a Cla-Val 210 Series Altitude Valve which should be installed in a horizontal run of pipe with the main valve cover up. Two line block valves are recommended for valve servicing. If the CDS6 is mounted from the main valve by a few feet, then it must be installed with adjustment springs up for ease of adjustment and servicing. Consult factory for recommendations.

After the Cla-Val 210 Series Altitude Valve is installed in the pipeline close to the reservoir, install the required remote sensing line from the CDS6 to the reservoir or tank. The sensing line allows the CDS6 to sense the static pressure head of the reservoir. The sensing line should not be installed in the flowing line between the valve and the reservoir or into turbulent flow area. These locations do not reflect the true static head of the reservoir.

The remote sensing line should be 3/4" or larger copper tubing or Schedule 40 PVC pipe. Galvanized pipe is not recommended. The sensing line should slope (minimum 2 degrees) upward from the CDS6 toward the reservoir to self -purge air out of the line. The sensing line should have no high points to entrap air. A shutoff valve at the reservoir connection is recommended. For above ground reservoirs, the connecting point for the sensing line should be a minimum of 12" to 18" above reservoir bottom (if filling from bottom) or at fill pipe connection (if filling from side). Minimum high-level set-point adjustment is approximately five feet above the remote sensing point of connection.

CDS6 STOCK NUMBER 2" SIZE	CDS6 STOCK NUMBER 2 1/2" SIZE & LARGER	ALTITUDE RANGE (FT H ₂ 0)	NUMBER OF SPRINGS	PSI CHANGE PER TURN	ALTITUDE CHANGE PER TURN
29330-06F	29330-01E	5 - 40	1	0.32	0.75
29330-07H	29330-02G	30 - 80	2	0.64	1.50
29330-08K	29330-03J	70 - 120	3	0.96	2.20
29330-09B	29330-04A	110 - 160	4	1.28	3.00
29330-10D	29330-05D	150 - 200	5	1.60	3.70

OPERATION, START-UP AND ADJUSTMENT

When the reservoir pressure (head) is lower than the setpoint of the spring on the CDS6 Altitude Control ports "1" and "D" are interconnected. This relieves the main valve cover pressure to atmosphere. Line pressure then opens the main valve to start filling the reservoir. Reservoir sensing pressure increases as the liquid level rises in the reservoir. When the sensing pressure increases to the set point of the CDS6 control spring, the control shifts interconnecting port "5" and port "1". This pressurizes the main valve cover chamber and the main valve closes.

By turning the adjusting nut the liquid level shutoff point will be changed. Turn the adjusting nut clockwise to raise the liquid level shutoff point; counterclockwise to lower the liquid level shutoff point. Follow the general operation and start-up instructions regarding purging air from the valve control system.

MAINTENANCE AND INSPECTION

Under normal operating conditions the CDS6 Altitude Control will be trouble free. There is a visual check possible to determine if there is damage to the diaphragm in the control. The Lower Cover/Pilot (a) is vented to atmosphere by means of a small hole in the wall of the casting. If water is discharging out of this opening, the diaphragm should be inspected for damage.

One other visual check and indication of a problem is continuous discharge from the drain port ("D") at the bottom of the CDS6.



The volume of drained water will vary according to the valve size. Continuous draining after main valve has fully opened will indicate a problem. Refer to the service suggestions to check for probable causes and remedies.

DISASSEMBLY

During preventive maintenance or service to the CDS6 Altitude Control, all pressure to the control must be shutoff. The CK2 shutoff cocks in the main valve control lines should be closed before starting disassembly. Main valves 4" and larger have CK2 cocks installed, however main valves smaller than 4" normally do not, therefore requiring closure of shutoff valves in the main line at the valve inlet and outlet. The shutoff cock or valve in the sensing line to the reservoir must also be closed.

WARNING: Failure to shutoff and release pressure prior to any disassembly can result in serious damage to equipment or injury to personnel.

- 1. Disconnect tubing at the CDS6 Altitude Control.
- 2. Remove two mounting caps screws and two lock washers.
- Remove CDS6 Altitude Control from main valve to work bench or clean area. Parts must be kept clean.

DISASSEMBLY OF UPPER SPRING SECTION

- Unscrew adjusting nut (4) from upper stem (5).
 NOTE: Count the number of turns required to remove the nut (4), record this information for reference when reassembling.
 The CDS6 Altitude Control can then be approximately reset for the same reservoir liquid level shut-off point.
- Remove the thrust washer (3), swivel retainer (2) and spring retainers if applicable.
- 3. Remove Spring(s) (6), bellows (7) and set-screw (8)
- 4. Remove twelve hex nuts (33), and twelve bolts (32), and set mounting bracket (29) aside.

Note: Assembly contains two (of twelve) longer bolts which are used for the mounting bracket.

- Remove upper cover (13) from lower assembly, and push stem assembly through.
- Remove diaphragm washer nut (12), diaphragm nut washer (16) and diaphragm (14)
- Separate upper stem from diaphragm washer by removing stem retaining pin. (11)
- 8. Inspect all parts for damage, wear and mineral deposits. Check O-ring (10) for wear, inspect and remove any deposit in O-ring area. Also inspect diaphragm for wear or cracks. Clean parts thoroughly and replace damaged parts as necessary. If, upon disassembly, sand and silt are found in the CDS6 Altitude Control, every effort must be made to eliminate this problem. Filters, or relocating the reservoir sensing line may be required if deposits are found in the sensing chamber of the control.

REASSEMBLY OF UPPER SPRING ASSEMBLY

- Reassembly is in general, the reverse of disassembly. NOTE: A light coating of Dow Corning 33 grease, or equivalent, should be applied to CDS6 Altitude Control stems (5), before reassembly.
- When replacing adjusting nut (4) tighten the same number of turns as referred to in **note** in paragraph (1) of "Disassembly Of Upper Spring Section".

DISASSEMBLY OF LOWER PILOT VALVE SECTION

- Disassemble control per steps 1 through 5 in "Disassembly of upper section", to work on lower (pilot) cover (17)
- 2. Remove lower stem (21) spring (19) and retaining ring (18) as an assembly, inspect stem for damage.
- 3. Remove Poppet guide (28) and o-ring (27) from lower cover (17).
- Remove Poppet (22-1) and poppet spring (26) and inspect poppet and disc for damage.
- 5. Remove Strainer screen (25)
- Remove seat (24), Note: be sure not to nick or ding exposed sealing surface. To prevent binding and damage, use a wood dowel to evenly tap out the seat from TOP of lower cover (area from which lower stem was removed).
- 7. Inspect all parts for damage, wear and mineral deposits. If there has been discharge from vent hole, remove o-ring (20) from lower cover (17) and poppet guide (28). Inspect o-rings for wear or damage and o-ring groove for material build-up. Clean and/or replace as necessary. Inspect seat (24) and disc poppet assembly (22) for wear or damage. If poppet and/or disc are damaged they must be replaced as an assembly (item 22). Otherwise clean and polish surfaces of moving parts with 600 wet/dry sandpaper. Also clean strainer screen (25) of any deposits

REASSEMBLY OF LOWER PILOT VALVE SECTION

- Reassembly is in general, the reversal of disassembly. Note: A light coating of Dow Corning 33 grease, or equivalent should be applied to all o-rings and moving part surfaces (20,21,22-1 23 and 27).
- Lay lower cover (17) on its top (do not damage serrated surface), insert the seat (24) with o-ring (23) in lower (pilot) cover with finger. Use a wood dowel to push the seat in fully with hand pressure ONLY. Note: damage to the seat can compromise the sealing ability of the control, and careful efforts must be applied on reassembly of this component.
- 3. Insert strainer (25).
- Install poppet guide, o-ring, spring and poppet assembly. (See Note #1 for greasing)

- Thread and securely fasten poppet guide assembly into lower cover (recommended 200-250 in/lbs.)
- Turnover lower cover, and assemble as an assembly lower stem (21) retainer (18) and spring (19) into lower cover, being careful not damage o-ring (20).

COMPLETING ASSEMBLY

- Reassembly of twelve nuts (33) and bolts (32) should be torqued to 200-250 in/lbs. Note: assembly contains two longer bolts (item 32) for the support bracket. These two bolts are to be assembled with bracket (29) on the two larger support flats located on the lower cover located 90 degrees from common/supply ports.
- 3. Install CDS6 Altitude Control assembly on main valve.
- 4. Replace tube lines and fittings exactly as removed.

SERVICE SUGGESTIONS

UPPER (SPRING) SECTION

SYMPTOM	PROBABLE CAUSE	REMEDY
Vent leaks in	Diaphragm (14) damaged	Replace diaphragm
lower cover (17)	Diaphragm nut (12) loose	Tighten nut (12)
	O-ring (20) damaged	Replace O-ring (20)
Leakage past stem	O-ring (10) damaged	Replace O-ring
stem (5)		
Stem (5) move-	*Sand or silt in sensing	Remove foreign matter
ment restricted	chamber above	from sensing chamber
or erratic	diaphragm	
	Sensing line clogged	Clean line
	Sensing line valve closed	Open valve fully
	Sensing line sagging or	Straighten and
	bent collecting sediment	support sensing line
		to reservoir
	Sensing line has high	Straighten sensing line.
	point trapping air in	Must slope upward
	the line	from altitude control
		to the reservoir


*NOTE: if this problem occurs, a sand trap should be installed in the sensing line, or the line moved to a point on the reservoir where sand or silt cannot enter this line.

SERVICE SUGGESTIONS

LOWER (PILOT VALVE) SECTION

SYMPTOM	PROBABLE CAUSE	REMEDY
Vent in lower cover (17) leaks	O-ring (20) worn or damaged. See Upper Spring Section service suggestion	Replace O-ring (20)
Flow from supply port to	Clogged strainer screen(25)	Remove screen and clean
valve cover port restricted	Silt packed in seat (24) and lower stem (21)	Clear area of blockage
Continuous drain leak. Main	Seat (24) damaged	Inspect and replace
valve closed	Disc in poppet assembly (22) damaged	Inspect and replace poppet assembly (22)
	Foreign object between disc and seat (24)	Remove object
	O-ring (20) in poppet guide (28) damaged	Replace O-ring
Continuous drain leak. Main valve open	Main valve diaphragm worn or stem nut loose	Service main valve. Replace diaphragm or tighten stem nut

Distributed By: M&M Control Service, INC.





- MODEL - X101

Valve Position Indicator & Pilot System Components



- Positive Visual Indicator
- Frictionless
- Leak Proof

В

NPT

1/4"

1/4"

1/4"

1/2"

1/2"

1/2"

34"

34"

1"

1"

1 1/4"

1 1/2"

2"


1"

- · Easy Maintenance and Cleaning
- Protected Indicator Rod

The Cla-Val Model X101 Visual Position Indicator is designed to display Cla-Val valve position quickly and easily. A solid brass indicator rod fastened directly to the valve stem moves up and down inside a pyrex tube. The tube is contained within a brass housing which is open on two opposite sides to permit clear vision of the indicator rod.

To purge air that may be trapped in the valve cover, a vent valve in the top of the housing is provided. Model X101 valve position indicator is furnished complete for installation on specified size Cla-Val Automatic Control Valve.

Dimensions



Dimension "A" is height added to valve by indicator assembly

Specifications

Sizes: 1" thru 24"

Materials: Brass, Pyrex Tube

Pressure Rating: 400 psi

Optional Material: Stainless Steel or Aluminum

Installation

Can be installed on any Cla-Val basic main valve in a few minutes. Simply replace the fitting on top of the valve cover with the indicator assembly.

When Ordering, Please Specify

- 1. Valve Size
- 2. Catalog No. X101
- 3. Valve Series No. (Appears on Valve Nameplate)
- Optional Material Stainless Steel or Aluminum



CSM-11 Solenoid Control

Body Material

Standard: Bronze with

Monel Trim

Option: Bronze with

Stainless Steel

Trim




CDS6 Altitude Control

Wetted Body Material

Standard: Bronze with

Stainless Steel

Trim





CDC-1 Check Valve



Size Body Material Trim Material
3/8"-1/2" Brass Delrin

CSC Swing Check Valve



Size Body Material Trim Material
3/8"-1" Brass Brass/Buna N

CN Series - Needle Valves



<u>Size</u> 1/4"-1" Body Material
Standard: Bronze
Option: Stainless Steel



Trim Material
Brass
Stainless Steel

CK Series - Shut-Off Cocks



<u>Size</u> 3/8"-1" Body Material
Standard: Bronze
Option: Stainless Steel

Trim Material
Stainless Steel/Teflon
Stainless Steel/Teflon




Represented By:



X-101

Valve Position Indicator



e rosition ma									
COMPLE	TE X101								
SIZE	STOCK NO.								
1 1/4 - 1 1/2	C2812A								
2	C8972G								
2 1/2	C2607E								
3	C2609A								
4	9710001A								
6	9710002J								
8	C8581F								
10	C9187A								
12	31420D								
14	30256C								
16	30251D								

ITEM	DESCRIPTION	MATERIAL
1	Vent Valve	Brass
2	Housing	Brass
3	*Gasket (2 Required)	Buna-N
4	*Sight Tube	Pyrex
5	Adapter	Brass
6	Busing	Brass
7	Stem	Brass
8	Stem Adapter	Brass

When ordering parts, please specify:

- All Nameplate data
- Item Number
- Description
- Material
- Part Number


Distributed By: M&M Control Service, INC.

*					<u> </u>		Ç	phiput	R CVCL	. 1(2)
-91 -96		CCC	LA-VAL	CO. NEWPORT	T BEACH, CALIFORNIA	PP - P/F		DRAWING	7656	<u> </u>
11-12			BELL REDUCERS	S. PIPE		Part Indian	A (NPT)	DESIGN BRAWN CHK'D.	D.S.	2-28 3-3-
3 B		\$1 <u>.</u>			B/ (NPT)			APP'D.	Jn, Jn, DC 026	3-3-
		1	CL	-VAL PART NO	. AND MATER	IAL			1	ZE
		BRONZE ASTM B584	STEEL	ST. STEEL	ALUM.	SEE BELOW	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		A	В
-		67656 - 01H	67656 - 22 D	67656-43 K	67656 - 64F				1/4	
9/3		- 02 F	-23 _B	. -4 4 н	- 65 C				3/8	in P Ind
, NED 406 7/8		- 03D	-24 K	- 45 E	-66A				1/2	1/
		- 04B	-25 G	- 46 C	-67 J	4			3/4	
The second second	8	- 05J	-26E	-47 A	-68 G				1	
102(- 06 G	-27 ℃	-48 J	-69 _E	316SST -101C			3/8	
	ri .	-07E	-28 _A	- 49 G	-70 _C	316SST -99B			1/2	
5 P/W -102G		-08 C	-2 9J	-50 E	-71A				3/4	1/
ADDED		-09A	- 30G	-51 C	-72 J				1	
H AI	·	-1 0 J	-31 _E	-52 A	- 73 G	316SS -97 F		SE SE En seu	1/2	
		-1 1 G	-32 _C	- 53 J	- 74 €	316 SS -96 H		2	3/4	3/
DATE	9-85	-12 E	-33A	- 54 G	-75 B				1	
	12-	-1 3 C	- 34J	-55 D	-76 K	2			3/4	
***	BH KH	-14 A	-35F	- 56. B	- 77 H				1	1/:
		- 15 H	-3 6D	-57 K	- 78 F	e e			14	
÷		-1 6 F	- 37 _B	–58 H	-79 D	MONEL -85A	8.5		1 <u>1</u>	
		-17 D	-38K	- 59 F	-80 в				1	
		-18 <u>B</u>	- 39 _H	-60 D	-81 K				14	3/4
		-1 9 K	-4 0F	-61 B	- 82 H			8.	1½	i V
DESCRIPTION	S	-2 0 н	-41 D	-62 _K	-83 F				14	***************************************
DESCR	KEV151UN 7715 35613	-21 _F	-42B	-63 H	-84 _D		a av	\$2 ************************************	$1\frac{1}{2}$	1
1	SEE KE ECO 77 NED 35	- 86 J	-87 _G	-88E	- 89℃	MONEL -90A			2	1/2
		99 1 J	-92 G	-93E	-94C	316SS -102G	de esta esta de la composição de la comp	various in contra	2	3/4
HQII	-100E, -101C,	-98 ^D	. The state of the	an	promotopie alektropologisco promotopie alektri (1909). Il ve especial	GALVINIZED IRON -95K	н (Напримент — Навадовичения поднат и	Pero La Calabra Van	2 1 /2	1
F	ADD - ADD -	-100E			1	If be returned to it upon act hereof be disclosed in fidentially and may not b pment or information sho e fully reserved by CLA-V.			2-1/2	1/2



81-01

3/8" Check Valve




Distributed By: M&M Control Service, INC.



CVC

Flow Check Control

Stock No. TV-3375



When ordering parts, please specify:

- Nameplate Data
- Item Number
- Description
- Part Description
- Material

Item	Description	Material	Material Item Descriptio		Material
1-5	Adjustment Assembly		7	Cover	Brass
1	Adjusting Stem	Brass	8	Spring Guide	Steel
2	Packing Gland	Brass	9*	Spring	S.S
3	Packing Washer (2)	Brass	10	Diaphragm Washer	Brass
4*	Packing 1/8" x 6"	Graphite	11*	Diaphragm	Buna N
5	Housing	Brass	12*	Disc Retainer Assembly	Brass Buna N
6	Machine Screw (10-32 x 1/2 Fil. Hd.) 8 re	Brass	13	Pipe Plug 3/8" NPT	Brass
	(10 02 X 1/2 1 II. 11d.) 0 10	·Y·	14	Body	Brass

Distributed By: M&M Control Service, INC.

INSTALLATION / OPERATION / MAINTENANCE



MODEL CVC

Flow Check Control

DESCRIPTION

The Flow Check is an adjustable hydraulically operated, diaphragm actuated, control. It opens for flow when a preset differential pressure exists across the control. The valve closes against a pressure reversal.

OPERATION

The Flow Check Control is normally closed. When the hydraulic forces at the inlet exceeds the combined hydraulic and spring force the valve opens for flow. When a pressure reversal occurs the hydraulic plus spring force prevents reversal of flow.

ADJUSTMENT (Range 1 to 15 feet of water)

To increase the differential to open the control, turn the adjusting screw clockwise. To decrease the differential to open the control, turn the adjusting screw counterclockwise.

INSTALLATION

Install the control cover up with the adjustment screw at the top. Allow clearance for adjustment screw. Place control in the line, noting the direction of flow. A flow arrow on the body casting clearly indicates direction.

DISASSEMBLY

Valve does not need to be removed from line to service.

- 1. Remove 4 10-32 machine screws on cover.
- 2. Remove cover with adjustment assembly attached.
- 3. Remove spring and spring seat.
- 4. Remove diaphragm assembly.

To disassemble diaphragm assembly:

- 1. Unscrew diaphragm washer from disc retainer assembly.
- 2. Remove diaphragm.

INSPECTION


Check diaphragm for damage due to wear or breaks. Check disc in disc retainer for damage, imbedded particles, breaks, scoring. Check valve seat for damage, wear, scoring. Check all parts for damage, corrosion, erosion, mineral buildup. Clean all parts thoroughly.

REASSEMBLY

Reassembly is the reverse order of disassembly. NOTE: The diaphragm, disc retainer and diaphragm washer must be tight. Tighten by hand. Attempt to turn the diaphragm between washers. If unable to turn, assembly is secured.

Distributed By: M&M Control Service, INC.

Phone: 800-876-0036 Fax: 847-356-0747



- 1. Place the diaphragm assembly on the valve body with the rubber disc insert down (next to seat).
- 2. Hole through casting into outlet end of body must be aligned with extra hole in diaphragm.
- 3. Place spring on diaphragm washer in center.
- 4. Place spring seat washer on top of spring.
- 5. Place cover on diaphragm.

NOTE: Extra hole in cover must align with extra hole through diaphragm and through body casting into outlet. Valve will not operate if hole outlet does not interconnect to cover chamber.

6. replace and tighten 4 13-32 machine screws.

TEST PROCEDURE

Apply pressure to outlet end with inlet open to atmosphere, control will close tight.

If Leakage occurs check for:


- 1. Damaged diaphragm, or refer to 2 in reassembly instruction.
- 2. Loose diaphragm assembly.
- 3. Damaged seat in body.
- 4. Damaged disc in disc retainer.

Email: Sales@mmcontrol.com

Apply pressure to inlet - outlet open to atmosphere.

NOTE: Variable pressure of 1 to 15 foot head of water should be used.

- 1. Turn adjustment screw in until it bottoms (do not force).
- 2. Back off 3 1/2 turns.
- 3. Control will open with approximately 15 foot head.
- 4. Turn adjusting screw counter clockwise to obtain lower settings.



"THIS DRAWING IS THE PROPERTY OF CLA-VAL CO. AND SAME AND COPIES MADE THEREOF, IF ANY, SHALL BE RETURNED TO IT UPON DEMAND. DELIVERY AND DISCLOSURE HEREOF ARE SOLELY UPON CONDITION THAT THE SAME SHALL NOT BE USED, COPIED OR REPRODUCED, NOR SHALL THE SUBJECT HEREOF BE DISCLOSED IN ANY MANNER TO ANYONE FOR ANY PURPOSE, EXCEPT AS HEREIN AUTHORIZED, WITHOUT PRIOR WRITTEN APPROVAL OF CLAY-VAL CO. THIS DRAWING IS SUBMITTED CONFIDENTIALLY AND MAY NOT BE USED IN THE MANUFACTURE OF ANY MATERIAL OR PRODUCT OTHER THAN SUCH MATERIALS AND PRODUCTS FURNISHED TO CLA-VAL CO. THIS INFORMATION SHOWN HEREON IS PATENTED OR OTHERWISE PROTECTED, FULL TITLE AND COPYRIGHTS, IF ANY, IN AND TO THIS DRAWING AND/OR INFORMATION DELIVERED OR SUBMITTED ARE FULLY RESERVED CLA-VAL CO."

INSTALLATION / OPERATION / MAINTENANCE



-MODEL- CV

Flow Control



DESCRIPTION

The Cla-Val Model CV Flow Control is a simply-designed, spring-loaded check valve. Rate of flow is full flow in one direction and restricted in other direction. Flow is adjustable in the restricted direction. It is intended for use in conjunction with a pilot control system on a Cla-Val Automatic Control Valve.

OPERATION

The CV Flow Control permits full flow from port A to B, and restricted flow in the reverse direction. Flow from port A to B lifts the disc from seat, permitting full flow. Flow in the reverse direction seats the disc, causing fluid to pass through the clearance between the stem and the disc. This clearance can be increased, thereby increasing the restricted flow, by screwing the stem out, or counter-clockwise. Turning the stem in, or clockwise reduces the clearance between the stem and the disc, thereby reducing the restricted flow.'

INSTALLATION

Install the CV Flow Control as shown in the valve schematic All connections must be tight to prevent leakage.

DISASSEMBLY

Follow the sequence of the item numbers assigned to the parts in the cross sectional illustration for recommended order of disassembly.

Use a scriber, or similar sharp-pointed tool to remove O-ring from the stem.

INSPECTION

Inspect all threads for damage or evidence of crossthreading. Check mating surface of seat and valve disc for excessive scoring or embedded foreign particles. Check spring for visible distortion, cracks and breaks. Inspect all parts for damage, corrosion and cleanliness.

CLEANING

After disassembly and inspection, cleaning of the parts can begin. Water service usually will produce mineral or lime deposits on metal parts in contact with water. These deposits can be cleaned by dipping the parts in a 5-percent muriatic acid solution just long enough for deposits to dissolve. This will remove most of the common types of deposits. Caution: use extreme care when handling acid. If the deposit is not removed by acid, then a fine grit (400) wet or dry sandpaper can be used with water. Rinse parts in water before handling. An appropriate solvent can clean parts used in fueling service. Dry with compressed air or a clean, lint-free cloth. Protect from damage and dust until reassembled.

REPAIR AND REPLACEMENT

Minor nicks and scratches may be polished out using a fine grade of emery or crocus cloth; replace parts if scratches cannot be removed.

Replace O-ring packing and gasket each time CV Flow Control is overhauled.

Replace all parts which are defective. Replace any parts which create the slightest doubt that they will not afford completely satisfactory operation. Use Inspection steps as a guide.

REASSEMBLY

Reassembly is the reverse of disassembly; no special tools are required.


TEST PROCEDURE

No testing of the flow Control is required prior to reassembly to the pilot control system on Cla-Val Main Valve.

Distributed By: M&M Control Service, INC.



3/8" Flow Control



Distributed By: M&M Control Service, INC.


INSTALLATION / OPERATION / MAINTENANCE




-MODEL-X46

Flow Clean Strainer









The X46 Flow Clean strainer operates on a velocity principle utilizing the circular "air foil" section to make it self cleaning. Impingement of particles is on the "leading edge" only. The low pressure area on the downstream side of the screen prevents foreign particles from clogging the screen. There is also a scouring action, due to eddy currents, which keeps most of the screen area clean.

1-3/4

2-1/4

2-1/2

2-1/2

3

3-3/8

4

4-1/4

4-1/2

4-1/4

A (NPT) B (NPT) D

1/8

1/4

3/8

1/2

1/2

3/4

3/4

1

1

1

1/4

3/8

3/8

1/2

3/8

3/4

3/8

1

1/2

X46A Straight Type A (In Inches)

3/4

1

1-1/4

1-1/4

2

2

2-3/4

2-3/4

2-3/4

1/2

3/4

7/8

1/2

1/2

1

1/2

1-1/4

1/2

1/2 1/4

3/4

7/8 1/2

7/8 3/4

1-1/8 3/4

> 1 7/8

1-1/2 7/8

1-3/8 7/8

1-3/4


1-3/8 7/8

3/8

7/8



Dimensions (In Inches)



X4	X46 Angle Type B (In Inches)									
B(NPT)	C(S/	AE) D	Е	Н	ı					
1/8	1/4	1-3/8	5/8	7/8	1/4					
1/4	1/4	1-3/4	3/4	1	3/8					
3/8	1/4	2	7/8	1	1/2					
3/8	3/8	1-7/8	7/8	1	1/2					
1/2	3/8	2-3/8	1	1-1/4	5/8					

When Ordering, Please Specify:

- Catalog Number X46
- Straight Type or Angle Type
- Size Inserted Into and Size Connection
- Materials

INSTALLATION

The strainer is designed for use in conjunction with a Cla-Val Main Valve, but can be installed in any piping system where there is a moving fluid stream to keep it clean. When it is used with the Cla-Val Valve, it is threaded into the upstream body port provided for it on the side of the valve. It projects through the side of the Main Valve into the flow stream. All liquid shunted to the pilot control system and to the cover chamber of the Main Valve passes through the X46 Flow Clean Strainer.

INSPECTION

Inspect internal and external threads for damage or evidence of cross-threading. Check inner and outer screens for clogging, embedded foreign particles, breaks, cracks, corrosion, fatigue, and other signs of damage.

DISASSEMBLY

Do not attempt to remove the screens from the strainer housing.

CLEANING


After inspection, cleaning of the X46 can begin. Water service usually will produce mineral or lime deposits on metal parts in contact with water. These deposits can be cleaned by dipping X46 in a 5-percent muriatic acid solution just long enough for deposit to dissolve. This will remove most of the common types of deposits. Caution: use extreme care when handling acid. If the deposit is not removed by acid, then a fine grit (400) wet or dry sandpaper can be used with water. Rinse parts in water before handling. An appropriate solvent can clean parts used in fueling service. Dry with compressed air or a clean, lint-free cloth. Protect from damage and dust until reassembled.

REPLACEMENT


If there is any sign of damage, or if there is the slightest doubt that the Model X46 Flow Clean Strainer may not afford completely satisfactory operation, replace it. Use Inspection steps as a guide. Neither inner screen, outer screen, nor housing is furnished as a replacement part. Replace Model X46 Flow Clean Strainer as a complete unit.

When ordering replacement Flow-Clean Strainers, it is important to determine pipe size of the tapped hole into which the strainer will be inserted (refer to column A or F), and the size of the external connection (refer to column B or G).

Distributed By: M&M Control Service, INC.



THIS DRAWING IS THE PROPERTY OF CLA-VAL CO. AND SAME AND COPIES MADE THEREOF, IF ANY, SHALL BE RETURNED TO IT UPON DEMAND. DELIVERY AND DISCLOSURE HEREOF ARE SOLELY UPON CONDITION THAT THE SAME SHALL NOT BE USED, COPIED OR REPRODUCED, NOR SHALL THE SUBJECT HEREOF BE DISCLOSED IN ANY MANNER TO ANYONE FOR ANY PURPOSE, EXCEPT AS HEREIN AUTHORIZED, WITHOUT PRIOR WRITTEN APPROVAL OF CLA-VAL CO. THIS DRAWING IS SUBMITTED CONFIDENTIALLY AND MAY NOT BE USED IN THE MANUFACTURE OF ANY MATERIAL OR PRODUCT OTHER THAN SUCH MATERIAL AND PRODUCTS FUNNISHED TO CLA-VAL CO. WHETHER OR NOT THE COUPMENT OR INFORMATION SHOWN HEREON IS PATENTED OR OTHERWISE PROTECTED, FULL TILE AND COPYRIGHTS, IF ANY, IN AND TO THIS DRAWING AND/OR INFORMATION DELIVERED OR SUBMITTED ARE FULLY RESERVED CLA-VAL CO.





X43 Strainer


ITEM	DESCRIPTION	MATERIAL
1	Pipe Plug	Steel
2	Strainer Plug	Brass
3	Gasket	Copper
4*	Screen	Monel
5	Body	Brass

*Replacement screen stock number 68373A.

All other parts available only in replacement assembly.

Standard 60 mesh pilot system strainer for fluid service.

SIZE	STOCK NUMBER
3/8 x 3/8	33450J



Distributed By: M&M Control Service, INC.



Cla-Val Product Identification

How to Order

Proper Identification

For ordering repair kits, replacement parts, or for inquiries concerning valve operation it is important to properly identify Cla-Val products already in service. Include all nameplate data with your inquiry. Pertinent product data includes valve function, size, material, pressure rating, end details, type of pilot controls used and control adjustment ranges.

Identification Plates

For product identification, cast in body markings are supplemented by identification plates as illustrated on this page. The plates, depending on type and size of product, are mounted in the most practical position. It is extremely important that these identification plates are not painted over, removed, or in any other way rendered illegible.




This brass plate appears on valves sized 2¹/₂" and larger and is located on the top of the inlet flange.



These two brass plates appear on 3/8", 1/2", and 3/4" size valves and are located on the valve cover.



This brass plate appears on altitude valves only and is found on top of the outlet flange.



This tag is affixed to the cover of the pilot control valve.

The adjustment range appears in the spring range section.




This aluminum plate is included in pilot system modification kits and is to be wired to the new pilot control system after installation.






These two brass plates appear on 1" through 3" size screwed valves or 1" through 2" flanged valves. It is located on only one side of the valve body.



This brass plate is used to identify pilot control valves. The adjustment range is stamped into the plate.



This brass plate is on our backflow prevention assemblies. It is located on the side of the number two check (2" through 10"). The serial number of the assembly is also stamped on the top of the inlet flange of the number one check.



HOW TO ORDER

There are many valves and controls manufactured by Cla-Val that are not listed due to the sheer volume. For information not listed, please contact your local Cla-Val office or our factory office located at:

P. O. Box 1325 Newport Beach, California 92659-0325 (949) 722-4800 FAX (949) 548-5441

SPECIFY WHEN ORDERING

- Model Number
- Globe or Angle Pattern
- Adjustment Range (As Applicable)
- Valve SizeScrewed or Flanged
- Body and Trim Materials
- Optional Features
- Pressure Class

UNLESS OTHERWISE SPECIFIED

- · Globe or angle pattern are the same price
- Ductile iron body and bronze trim are standard
- X46 Flow Clean Strainer or X43 "Y" Strainer are included
- CK2 Isolation Valves are included in price on 4" and larger valve sizes (6" and larger on 600 Series)

LIMITED WARRANTY

Automatic valves and controls as manufactured by Cla-Val are warranted for three years from date of shipment against manufacturing defects in material and workmanship which develop in the service for which they are designed, provided the products are installed and used in accordance with all applicable instructions and limitations issued by Cla-Val.

We will repair or replace defective material, free of charge, which is returned to our factory, transportation charges prepaid, provided that, after inspection, the material is found to have been defective at time of shipment. This warranty is expressly conditioned on the purchaser's giving Cla-Val immediate written notice upon discovery of the defect.

Components used by Cla-Val but manufactured by others, are warranted only to the extent of that manufacturer's guarantee.

This warranty shall not apply if the product has been altered or repaired by others, and Cla-Val shall make no allowance or credit for such repairs or alterations unless authorized in writing by Cla-Val.

DISCLAIMER OF WARRANTIES AND LIMITATIONS OF LIABILITY

The foregoing warranty is exclusive and in lieu of all other warranties and representations, whether expressed, implied, oral or written, including but not limited to any implied warranties or merchantability or fitness for a particular purpose. All such other warranties and representations are hereby cancelled.

Cla-Val shall not be liable for any incidental or consequential loss, damage or expense arising directly or indirectly from the use of the product. Cla-Val shall not be liable for any damages or charges for labor or expense in making repairs or adjustments to the product. Cla-Val shall not be liable for any damages or charges sustained in the adaptation or use of its engineering data and services. No representative of Cla-Val may change any of the foregoing or assume any additional liability or responsibility in connection with the product. The liability of Cla-Val is limited to material replacements F.O.B. Newport Beach, California.

TERMS OF SALE

ACCEPTANCE OF ORDERS

All orders are subject to acceptance by our main office at Newport Beach, California.

CREDIT TERMS

Credit terms are net thirty (30) days from date of invoice.

PURCHASE ORDER FORMS

Orders submitted on customer's own purchase order forms will be accepted only with the express understanding that no statements, clauses, or conditions contained in said order form will be binding on the Seller if they in any way modify the Seller's own terms and conditions of sales.

PRODUCT CHANGES

The right is reserved to make changes in pattern, design or materials when deemed necessary, without prior notice.

PRICES

All prices are F.O.B. Newport Beach, California unless expressly stated otherwise on our acknowledgement of the order. Prices are subject to change without notice. The prices at which any order is accepted are subject to adjustment to the Seller's price in effect at the time of shipment. Prices do not include sales, excise, municipal, state or any other Government taxes. Minimum order charge \$75.00.

RESPONSIBILITY

We will not be responsible for delays resulting from strikes, accidents, negligence of carriers, or other causes beyond our control. Also, we will not be liable for any unauthorized product alterations or charges accruing there from.

RISK

All goods are shipped at the risk of the purchaser after they have been delivered by us to the carrier. Claims for error, shortages, etc., must be made upon receipt of goods.

EXPORT SHIPMENTS

Export shipments are subject to an additional charge for export packing.

RETURNED GOODS

- Customers must obtain written approval from Cla-Val prior to returning any material.
- Cla-Val reserves the right to refuse the return of any products.
- 3. Products more than six (6) months old cannot be returned for credit.
- ${\bf 4.} \quad {\bf Specially \ produced, \ non-standard \ models \ cannot \ be \ returned \ for \ credit.}$
- Rubber goods such as diaphragms, discs, o-rings, etc., cannot be returned for credit, unless as part of an unopened vacuum sealed repair kit which is less than six months old.
- Goods authorized for return are subject to a 35% (\$75 minimum) restocking charge and a service charge for inspection, reconditioning, replacement of rubber parts, retesting, repainting and repackaging as required.
- Authorized returned goods must be packaged and shipped prepaid to Cla-Val, 1701 Placentia Avenue, Costa Mesa, California 92627.



Distributed By:

M&M Control Service, INC.

Phone: 800-876-0036 Fax: 847-356-0747

Email: Sales@mmcontrol.com

E-Product I.D. (R-11/01)

INSTALLATION / OPERATION / MAINTENANCE



- MODEL - REPAIR KITS

Complete Replacement Diaphragm Assemblies for 100-01 and 100-20 Hytrol Main Valves For: Hytrol Main Valves with Ductile Iron, Bronze Trim Materials—125/150 Pressure Class Only. **FACTORY ASSEMBLED**

Includes: Stem, Disc Guide, Disc, Disc Retainer, Spacer Washers, Diaphragm, Diaphragm Washer and Stem Nut.

Valve Size		Diaphragm Assembly Stock Number		Valve Size	Diaphragm Assembly Stock Number	
O12C		100-01	100-20	0.20	100-01	100-20
3/8"	(Also 81-01)	49097K	N/A	6"	40456G	33273E
1/2" - 3/4"	(Also 81-01)	C2518D	N/A	8"	45276D	40456G
1"		C2520K	N/A	10"	81752J	45276D
1 1/4"-1 1/2"		C2522 F	N/A	12"	85533J	81752J
2"		C2524B	N/A	14"	89067D	N/A
2 1/2"		C2523D	N/A	16"	89068B	85533J
3"		C2525J	C2524B	20"	N/A	89068B
4"		33273E	C2525J	24"	N/A	89068B

Repair Kits for 100-01/100-20 Hytrol Valves

For: Hytrol Main Valves—125/150 Pressure Class Only.

Supplied Shrink Wrapped (4" and smaller) or Bagged (6" and larger)

Includes: Diaphragm, Disc (or Disc Assembly) and spare Spacer Washers.

E	Buna-N Standard Material			Viton (For KB Valves)			
Valve Size		Repair Kit Stock Number		Valve Size		Repa Stock N	ir Kit Number
		100-01	100-20			100-01	100-20
3/8"	(Also 81-01)	9169801K	N/A	3/8"	(Also 81-01)	9169806J	N/A
1/2" - 3/4"	(Also 81-01)	9169802H	N/A	1/2" - 3/4"	(Also 81-01)	9169807G	N/A
1"		9169803F	N/A	1"		9169808E	N/A
1 1/4" - 1 1/2"		9169804D	N/A	1 1/4" - 1 1/2"		9169809C	N/A
2"		9169805A	N/A	2"		9169810A	N/A
2 1/2"		9169811J	N/A	2 1/2"		9169817F	N/A
3"		9169812G	9169805A	3"		9169818D	9169810A
4"		9169813E	9169812G	4"		9169819B	9169818D
6"		9169815K	9169813E	6"		9169820K	9169819B
8"		9817901D	9169815K	8"		N/A	9169820K
10"		9817902B	9817901D				
12"		9817903K	9817902B				
14"		9817904H	N/A				
16"		9817905E	9817903K				
20"		N/A	9817905E				
24"		N/A	9817905E				

When ordering, please give complete nameplate data of the valve and/or control being repaired. MINIMUM ORDER CHARGE APPLIES.

Repair Kits for 100-02/100-21 Powertrol and 100-03/100-22 Powercheck Main Valves

For: Powertrol and Powercheck Main Valves—125/150 Pressure Class Only

Supplied Shrink Wrapped (4" and Smaller) or Bagged (6" and larger)

Includes: Diaphragm, Disc (or Disc Assembly) and spare Spacer Washers.

Valve	Kit Stock Number	Valve	Kit Stock Number		
Size	100-02	Size	100-02 &100-03	100-21 &100-22	
3/8"	9169901H	2 1/2"	9169910J	N/A	
1/2" - 3/4"	9169902F	3"	9169911G	9169905J	
1"	9169903D	4"	9169912E	9169911G	
1 1/4" & 1 1/2"	9169904B	6"	9169913C	9169912E	
2"	9169905J	8"	99116G	9169913C	
		10"	N/A	99116G	

Larger Sizes: Consult Factory.

Repair Kits for 100-04/100-23 Hy-Check Main Valves

For: Hy-Check Main Valves—125/150 Pressure Class Only

Supplied Shrink Wrapped (4" and Smaller) or Bagged (6" and larger)

Includes: Diaphragm, Disc and O-Rings and full set of spare Spacer Washers.

Valve	Kit Stock Number		Valve	Kit Stock	Number
Size	100-04	100-23	Size	100-04	100-23
4"	20210901B	N/A	12"	20210905H	20210904J
6"	20210902A	20210901B	14"	20210906G	N/A
8"	20210903K	20210902A	16"	20210907F	20210905H
10"	20210904J	20210903K	20", 24"	N/A	20210907F

Larger Sizes: Consult Factory.

Repair Kits for Pilot Control Valves

Supplied Shrink Wrapped Includes: Diaphragm, Disc (or Disc Assembly), O-Rings, Gaskets or spare Screws as appropriate.

BUNA-N	VITON (For KB Controls)				
Pilot Control	Kit Stock Number	Pilot Control	Kit Stock Number	Pilot Control	Kit Stock Number
CDB	9170006C	CFM-7 & 7-A	1263901K	CDB-KB	9170012A
CDB-7	9170017K	CRA (w/bucking spring)	9170001D	CRA-KB	9170018H
CDH-2	18225D	CRD (w/bucking spring)	9170002B	CRD-KB (w/bucking spring)	9170008J
CDHS-2	44607A	CRD (no bucking spring)	9170003K	CRL-KB	9170013J
CDHS-2B	9170004H	CRD-22	98923G	CDHS-2BKB	9170010E
CDHS-2F	9170005E	CRL (55F, 55L)	9170007A	CDHS-2FKB	9170011C
CDHS-3C-A2	24657K	CRL-4A	43413E	CDHS-18KB (no bucking spring)	9170009G
CDHS-8A	2666901A	CRL-5 (55B)	65755B	102C-KB	1726202D
CDHS-18	9170003K	CRL-5A (55G)	20666E	Buna-N®	
CDS-4	9170014G	CV	9170019F		
CDS-5	14200A	X105L (O-ring)	00951E	CRD DISC RET. (SOLID)	C5256H
CDS-6	20119301A	102B-1	1502201F	CRD DISC RET. (SPRING)	C5255K
CFM-2, CFM-9, CFCM-M1	12223E	102C-2 & -3	1726201F		

Repair Assemblies (In Standard Materials Only)

Control	Description	Stock Number
CF1-C1 CF1-CI CFC2-C1 CSM 11-A2-2 CSM 11-A2-2 33A 1" 33A 2"	Pilot Assembly Only Complete Float Control less Ball & Rod Disc, Distributor & Seals Mechanical Parts Assy. Pilot Assembly Only Complete Internal Assembly & Seal Complete Internal Assembly & Seal	89541H 89016A 2674701E 97544B 18053K 2036030B 2040830J

When ordering, please give complete nameplate data of the valve and/or control being repaired. MINIMUM ORDER CHARGE APPLIES

Distributed By: M&M Control Service, INC.